

This economy, pocket sized, 60° gloss meter offers high quality measurement and is very easy to use.

The steel case protects the optical system and the electronics either in the lab, in the workshop, or in the field.

Features

- Easy to use - one button operation
- Automatic digital push button calibration
- Range: 0.1-100 GU, repeatability: ± 0.5 GU, precision: ± 1 GU
- Large backlit LCD display, visible even in low light area
- Automatic power off and low battery warning
- Powered by mains/rechargeable batteries (900 readings/ charge)



Standards

Conforms to International Standard ISO 7668.

Product specifications

Function	Description
Measuring geometry	60 Degrees
Range	0.1 to 100 gloss units
Accuracy	± 1.0 gloss unit (against reference standard)
Resolution	0.1 gloss unit
Repeatability	Better than ± 0.5 gloss unit (10 readings)
Charger voltage	100 – 240V (50 – 60Hz)
Dimensions	(L x W x H) 110 x 45 x 85mm (4.33" x 1.77" x 3.35")
Weight	800g (1.8 lbs) (including fitted rechargeable batteries)
Temperature range	0 – 40°C (32 – 104°F) (Non – condensing)

Appearance: Gloss: **Minigloss 60° Glossmeter**

Maintenance/Calibration

Routine user calibration is possible using calibration standard supplied however it is recommended that the instrument be serviced and calibrated routinely by one of our approved service centres in order to ensure optimum performance.

Standard supply includes:

- Instrument
- Certified standard
- Charger
- Carrying case

Ordering information

Product Ref	Description
SH101N	Minigloss 60° Glossmeter
	Accessories
101N/004/S	Replacement high gloss reference tile
155/605/P	Replacement battery charger

Owing to continuous development, we reserve the right to introduce improvements and modify specifications without prior notice.

**Our sales team can be contacted on:
info@sheeninstruments.com or +44 (0)208 783 4321**